

Panasonic[®]

Model No. **KX-TG8231**
KX-TG8232

Quick Guide


Routine care

- To clean the product, use a dry soft cloth. The outer surface of the product can be scratched by wiping or rubbing with a hard cloth.

Setting up


Base unit

- Use only the supplied Panasonic AC adaptor PQLV207.
- Use only the supplied telephone line cord.




Handset

- **USE ONLY Ni-MH batteries AAA (R03) size.**
- **Do NOT use Alkaline/Manganese/Ni-Cd batteries.**
- **Ensure correct polarities (⊕, ⊖) when installing the batteries.**




Charger (KX-TG8232)

- Use only the supplied Panasonic AC adaptor PQLV209.




CHARGE 7 HOURS



PQQW15858ZA DC0707YK0

Screen saver mode

The backlight will turn off completely after 1 minute of inactivity if the handset is not on the base unit or charger. Press **[OFF]** to turn the display on again.




Operating tips

[]: shows button names.


Using the joystick

The handset joystick can be used to navigate through menus and to select items shown on the display, by pushing it up **[▲]**, down **[▼]**, left **[←]**, or right **[→]**.




Adjusting the receiver or speaker volume

Push the joystick up **[▲]** or down **[▼]** repeatedly while talking.



Soft keys

The handset features 2 soft keys and a joystick. By pressing a soft key, or by pressing the center of the joystick, you can select the feature shown directly above it on the display.



Menu icons


When in standby mode, pressing down on the center of the joystick reveals the handset's main menu. From here you can access various features and settings.

| Icon | Feature and settings |
|------|----------------------|
| | View Caller ID |
| | Display settings |
| | Set date & time |

| Icon | Feature and settings |
|------|----------------------|
| | Answering device |
| | Initial settings |
| | Customer support |















For further information, visit <http://www.panasonic.com/help> or refer to Operating Instructions.

Date and time (Handset)










- 1 **[MENU]** (center of joystick)
- 2 Select  by pushing the joystick in any direction. → **[SELECT]**
- 3 Push the joystick up or down to select "Date and time" → **[SELECT]**
- 4 Enter the current month, date, and year.
- 5 Enter the current hour and minute (12-hour clock format).
- 6 Press **[*]** to select "AM" or "PM". → **[SAVE]** → **[OFF]**

Basic operations

Making/Answering calls (Handset)


| | |
|--|---|
| Making calls | Dial the phone number. → []/[ |
| Answering calls | []/[ |
| Hanging up | [OFF] |
| Receiver/speaker volume | Push the joystick up or down repeatedly while talking. |
| Making a call using the redial list | [REDIAL] → []/[: Select the desired number. → [ |
| Handset ringer volume | <ol style="list-style-type: none"> 1 [MENU] (center of joystick) →  → [SELECT] 2 []/[: "Ringer settings" → [SELECT] 3 []/[: "Ringer volume" → [SELECT] 4 []/[: Select the desired volume. → [SAVE] → [OFF] |
| Answering call-waiting call (2nd call) | Press [CALL WAIT] when you hear call-waiting tone. |


Phonebook (Handset)

| | |
|--|--|
| Adding entries (names and phone numbers) | <ol style="list-style-type: none"> 1 [] (left soft key) 2 [ADD] 3 Enter the party's name (16 characters max.). → [OK] 4 Enter the party's phone number (24 digits max.). → [OK] 5 []/[: Select the desired group. → [SELECT] 6 []/[: "Save" → [SELECT] → [OFF] <ul style="list-style-type: none"> • To enter a name, see the character table in the operating instructions. |
| Making calls | <ol style="list-style-type: none"> 1 [] (left soft key) 2 []/[: Select the desired entry. → [ |

| Basic operations | |
|-------------------------------------|---|
| Answering system (Base unit) | |
| Answering on/off | Press [ON] (ANSWER ON) to turn on/off the answering system. |
| Listening to new messages | When the Message indicator flashes on the base unit, press [▶] (Message). |
| Listening to old messages | When the Message indicator does not flash on the base unit, press [▶] (Message). |

| Frequently asked questions | |
|--|--|
| Question | Cause/solution |
| How can I increase handset volume level? | <ul style="list-style-type: none"> ● Push the joystick up [▲] repeatedly while talking. |
| Why is the conversation noisy or cutting off? | <ul style="list-style-type: none"> ● Try to relocate the base unit so that distance from location to use the handset will be minimized. ● Send your unit to service, if your unit has same problem when the handset is next to the base unit. |
| Can I add another accessory handset to my base unit? | <ul style="list-style-type: none"> ● Yes, you can add up to 6 handsets (including the handset(s) sold with your own base unit) to a single base unit. ● To purchase accessory handset (KX-TGA820), please visit http://www.panasonic.com or call 1-800-332-5368. TTY users (hearing or speech impaired users) can call 1-866-605-1277. |
| Can I keep battery charging all the time? | <ul style="list-style-type: none"> ● You can leave handset on the base unit or charger anytime. This will not harm the battery. |
| How can I answer a call-waiting call (2nd call)? | <ul style="list-style-type: none"> ● Press [CALL WAIT] when you hear call-waiting tone. |
| Why is "New Voice Mail" not displayed on the handset even though I have new messages in my voice mail service? | <ul style="list-style-type: none"> ● Your service provider/telephone company needs to provide the signal for visual message waiting indicator. Consult your service provider/telephone company of your Voice Mail service. ● If you hear the "interrupted" dial tone, new messages are waiting. You can check if you have new messages by simply listening to the dial tone even if you cannot be provided the visual message waiting signal. ● To use the Voice Mail service provided by your service provider/telephone company rather than the unit's answering system, turn off the answering system. |







Registering a handset to base unit

The supplied handset and base unit are preregistered. If for some reason the handset is not registered to the base unit, register the handset.

Handset


- 1 **[MENU]** (center of joystick) →  → **[SELECT]**
- 2 **[▼]/[▲]**: "Registration" → **[SELECT]**
- 3 **[▼]/[▲]**: "HS registration" → **[SELECT]**



Base unit


Press and hold **[••]** (LOCATOR) for about 5 seconds, until the registration tone sounds.

- Complete next step within 1 minute and 30 seconds.



Handset

Press **[OK]**, then wait until a confirmation tone sounds and **Y** stops flashing.



For further registration information, visit
<http://www.panasonic.com/RegisterYourHandset>

IMPORTANT!

If your product is not working properly. . .

1 Read this Quick Guide or Operating Instructions

- If you lost the Operating Instructions, you can download a copy at <http://www.panasonic.com/help>

2 Visit our website:

<http://www.panasonic.com/help>

- FAQs and troubleshooting hints are available.

3 Contact us via the web at:

<http://www.panasonic.com/contactus>

4 Call us at:

1-800-211-PANA (1-800-211-7262)

- Monday - Friday 9:00am - 9:00pm (EST),
Saturday/Sunday 10:00am - 7:00pm (EST)

To order a replacement battery,
please call: 1-800-332-5368

Or visit: <http://www.panasonic.com/batterystore>