



NE-SCV3 CLEANING GUIDE


Daily



Cool Down Oven: Press the 280°C rectangle on the display.



Initiate Cool Down: Select cooling, and slightly open the door (about 1/4 open) until it holds naturally. Press start to begin the cool down.




Complete Cool Down: Once the cool down finishes, press OK on the screen to start cleaning.



Soak Cook Plate: Remove the cook plate and place it in a bowl of hot, soapy water to soak.



Clean Interior: With the cook plate removed, clean the cavity's side and back walls, as well as the door and back of the oven, using hot, soapy water and a green scouring pad. Dry thoroughly with paper towels.




Clean Drip Crumb Collector: Remove the drip crumb collector below the door, clean it with hot, soapy water, dry it, and gently replace it.

NE-SCV3 CLEANING GUIDE

Daily



7



Clean Filters: Remove the filter by tilting it forward and pulling up. Take out the inner mesh filter, wash both with warm, soapy water, and dry with paper towels. Wipe the bottom of the slot before reinserting the mesh filter and reattaching the whole filter.

8



Clean Exterior: Use D10 and a blue cloth to clean the outside of the oven, ensuring all touch points are thoroughly cleaned.

9



Final Wipe Down: Go over the oven with a dry paper towel to remove any excess moisture and give it a shine.

NE-SCV3 CLEANING GUIDE

Monthly



1



Clean Drip Tray: Remove the front filter and pull out the drip tray. Wash with hot, soapy water, dry, and replace it.

2



Scrub Exhaust Vent: Scrub the back of the oven's exhaust vent with a damp green scouring pad to remove grease. Dry thoroughly with a paper towel.

3



Clean Power Cable: Wipe the power cable with a damp green scouring pad to remove grease or grime. Dry thoroughly with paper towels. Also, clean the countertop area exposed when moving the oven before returning it to its original position.